

# **Conformal Coating**

# **Technical Data Sheet**

# 101E Low VOC Acrylic Conformal Coating

101E is a Toulene and Xylene free, single part, fast drying, superior, acrylic conformal coating for printed circuit assemblies and electrical equipment. This Low VOC coating is used in all areas of high-end electronics including aerospace, military, and automotive engineering and meets Mil-I-46058C and IPC-CC-830 Qualifications.

- Offers complete protection from harsh environment conditions such as high humidity, dust, corrosion, fungus, salt and thermal extremes
- Low VOC Coating allowing use where solvent emissions are critical.
- Meets MIL-I-46058C and IPC-CC-830 Qualifications
- · Easily reworked using solvents using Trinity Shields Thinners and Strippers
- High speed drying allows efficient electronic production processing
- RoHS-2 compliant (2011/65/EU)
- Coating does not contain > 0.10% of any candidate substances of very high concern (SVHC) per Article 59(10) or REACH Regulations
- All materials and substances in this product have been pre-registered or are exempt from REACH Registration

Physical Properties	Colour:	Water white amber sl
---------------------	---------	----------------------

Clarity: Clear

Odor: Sweet Solvent

Viscosity @ 24°C (cps):190-210Specific Gravity:0.9538VOC Content (%):49%Flash Point:16°CSolids Content (w/w%):41

**Electrical Properties** Dielectric strength (kV/mil): 1.538

Dielectric Constant (1 GHz): 3.53
Dissipation Factor (1 GHz): 0.0556
Moisture Resistance (Mil-I-46058C): Passes
Volume Resistivity: 1.5x10<sup>13</sup>

Physical Performance Temperature Range: -62°C to 127°C

Coverage @ 25um: 14m<sup>2</sup> Per litre (bulk)

Adhesion: Excellent Thermal Cycling (Mil-I-46058C) Passes

Work Schedule Dry to Touch: 8-12 minutes

Tack Free time: 20-30 minutes

Recommended Dry time: 24 hours @ room temperature

2 hours @ 90°C



#### **APPLICATION**

#### Cleaning

In general PCBs should be thoroughly cleaned before coating. This is required to ensure that satisfactory adhesion to the substrate is possible. Also all flux residues must be removed as they become corrosive if left on the PCB.

# **Dip Coating**

Ensure that the coating material in the container has been agitated thoroughly and has been allowed to stand for at least 2 hours for all the air bubbles to disperse.

Thinners (Thinner E) should be used to keep the 101E coating at a suitable viscosity for dipping. Thinner E is added periodically as the solvent evaporates. The viscosity should be checked using a viscosity meter or "flow cup" on a regular basis.

The board assemblies should be immersed in the 101E dipping tank in the vertical position, or at an angle as close to the vertical as possible. It is possible to dip a PCB horizontally and Trinity and its agents would be happy to help with this process. Connectors should not be immersed in the liquid unless they are very carefully masked.

For good penetration it may be necessary to leave the circuit board submerged for a short time until the air bubbles have dispersed. The board or boards should then be withdrawn VERY SLOWLY so that an even film covers the surface. Typical withdrawal rates are 10-20 cm/min (4-8"/min). After withdrawing, the boards should be left to drain over the tank until the majority of residual coating has left the surface.

After the draining operation is complete, the boards should be placed in an air-circulating drying cabinet and left to dry.

### **Bulk Spraying**

Bulk 101E needs to be thinned with Trinity thinner (Thinner E) before spraying. The optimum viscosity to give coating quality and thickness depends on the spray equipment and conditions but a starting point could be 2 parts coating to 1-part thinners. If the bulk coating material has been agitated, allow to rest until air bubbles have dispersed.

101E is suitable both for use in manual spray guns and selective spray equipment.

A good technique is to hold the gun at 45 degrees angle and a distance of approximately 20-25cm while spraying. Spray a thin and continuous film onto the circuit with an even motion. Turn the circuit 90 degrees and repeat the process. Rotate a full 360 degrees to cover all sides of the circuit.

This process helps to ensure penetration of the coating beneath the components and in confined spaces. Allow the coating to dry for a few minutes. Apply a second coat as required to meet any coating thickness requirements specified.

After spraying, the boards should be placed in an air-circulating drying cabinet and left to dry for handling.



# **Aerosol Spraying**

Avoid shaking the can before use. This may add excessive bubbles and give a poorer finish.

A good technique is to hold the aerosol can at 45 degrees angle and a distance of approximately 20-25cm while spraying. Spray a thin and continuous film onto the circuit with an even motion. Turn the circuit 90 degrees and repeat the process. Rotate a full 360 degrees to cover all sides of the circuit.

### **Brushing**

Ensure that the coating material has been agitated thoroughly and has been allowed to settle for at least 2 hours. The coating should be kept at ambient temperature. Gently apply the coating with a good quality brush so as not to leave brush marks and so that the components and wiring are not disturbed. Dilution by 5-10% using Thinners E can aid in the flow of the conformal coating during application.

# **Drying Times & Curing Conditions**

101E will be touch dry after 8-12 minutes at room temperature and does not require a thermal cure. The full properties of 101E will be obtained after a 24 hours at room temperature. This can be accelerated by the use of a thermal cure of 2 hours at 90°C or 4 hours at 60°C.

### **Coating Removal & Repair**

101E can be easily removed using Stripper S101E, which can be locally or completed stripped depending on requirements. Application can be achieved using a cotton bud, brush or complete immersion in a bath of S101E. Compatibility of the S101E with the PCB should be assessed at all times.

#### Inspection

The 101E conformal coating has a UV trace within the coating itself, which fluoresces under UV light. This aids inspection of the material after drying and during coating application. Suitable lighting includes UVA.

	Packaging	Order Code	Shelf Life
101E Conformal Coating	400ml Aerosol 1 Litre Bulk 5 Litre Bulk	101EAerosol 101E 1L 101E 5L	2 Years 2 Years 2 Years
Thinner E	5 Litre	ThinnerE5L	2 years
Stripper S101E	5 Litre	StripperS101E5L	2 years

# **Copyright Trinity Shield 2015**

This product is designed exclusively for industrial use and is sold "as is." The manufacturer makes no warranties, guarantees, or representations of any kind to the buyer or the user, either express or implied, with regard to the product sold or use of the product, including, but not limited to, merchantability, fitness for a particular purpose or use, or eligibility of the product for any particular trade usage. Expect as expressly stated herein, the manufacturer makes no warranty of results to be obtained by use of this product. Buyer's or user's exclusive remedy, and the manufacturer's or seller's total liability shall be limited to damages not exceeding the cost of the product. No agent or the seller is authorized to amend the terms of this warranty disclaimer or the product's label or to make a presentation or recommendation different of inconsistent with the label of this product.

Trinity Shields LLC 5729 Lebanon Road Suite 144 #338 Frisco, TX USA +1+347-234-5388 info@trinityshields.com